

Turris Omnia Reference Platform: Flashing Instruction

- [Turris Omnia 2019 & 2020: Flashing Instruction](#)
 - [Hardware Information](#)
 - [Requirements](#)
 - [Flashing RDKB image \(A Yocto Project based Distro\)](#)
 - [Flashing with Medkit & Sysupgrade images](#)
 - [Creating additional partitions](#)
 - [RDK Firmware\(Image\) upgrade: \(Yet to validate\)](#)
 - [Approach 1:](#)
 - [Approach 2\(Quick\):](#)
- [Turris Omnia RTROM01-2G & RTROM01-CE: Flashing Instruction](#)
 - [Hardware Information](#)
 - [Serial Port Access](#)
 - [Setting up Bootloader:](#)
 - [Setting default U-boot environment](#)
 - [Flashing](#)
 - [Flashing RDKB image \(A Yocto Project based Distro\)](#)
 - [RDK Firmware\(Image\) upgrade:](#)
 - [Approach 1:](#)
 - [Approach 2\(Quick\):](#)
 - [Approach 3:](#)
 - [Fallback to OpenWrt OS\(Failsafe\):](#)