

Where is dsGetHDMIDDCLineStatus?

If I turn on the definition - "_INIT_RESN_SETTINGS" in iarmmgrs, I will get error log:

```
dsMgr.c:387: error: undefined reference to 'dsGetHDMIDDCLineStatus()'
```

In fact, I can't find that function definition - dsGetHDMIDDCLineStatus .

Is it a new API ?

```
| dsMgr.c:387: error: undefined reference to 'dsGetHDMIDDCLineStatus()'
```