Tagged RDKB_Extender build for August2021

Host Setup

- For Host Setup details, refer this link – How to Build#SettinguptheHostEnvironment

Initilaizing the Build Environment

Note: Cloning the code before login once to code.rdkcentral.com, user would get the Authentication error, even though the account is in good standing and has all the required access. Please login to code.rdkcentral.com before attempting to clone.

Build Instruction

Follow below build instructions

```
mkdir <workspace dir>

cd <workspace dir>

repo init -u https://code.rdkcentral.com/r/reference/manifests -m turris-tags/Turris_rdkb_extender_6Sept21.xml -
b master

repo sync -j4 --no-clone-bundle

MACHINE=turris-extender source meta-turris/setup-environment build-turris-ext

bitbake rdk-generic-extender-image
```

The kernel Image and root filesystem will be placed under <workspace dir>/build-turris-ext/tmp/deploy/images/turris-extender

Recent Fixes

- Resolved the issue in invoking dhcp_script for every DHCP lease offer; Should be able to see all Connected client in Plume NoC

Supported Features

S.No	Feature Name
1	Wi-Fi Extender Use case

Flashing Procedure

- **Turris Omnia Reference Platform: Flashing Instruction**