

the trace of TR069Pa

Hello Guys,

I noticed there are several styles of trace code lines in TR069Pa. I want to know the trace format `CcspTraceWarning2("ms", (xxxx))`, where I can find the logs?

such as the below line. what's the meaning of ms? where the trace output?

Thank you!

```
CcspTraceDebug2("ms", ("CcspManagementServer_RegisterWanInterface pFirstUpstreamIpAddress is %s\n", pFirstUpstreamIpAddress));
```