How to enter "factory mode" for RDK-B?

And how to build a production image, after production activities, we can switch the image from "factory mode" to normal mode.