

# Turris Omnia Reference Platform: Flashing Instruction

- [Turris Omnia 2019 & 2020: Flashing Instruction](#)
  - [Hardware Information](#)
  - [Requirements](#)
  - [Flashing RDKB image \(A Yocto Project based Distro\)](#)
    - [Flashing with Medkit & Sysupgrade images](#)
    - [Creating additional partitions](#)
  - [RDK Firmware\(Image\) upgrade: \(Yet to validate\)](#)
    - [Approach 1:](#)
    - [Approach 2\(Quick\):](#)
- [Turris Omnia RTROM01-2G & RTROM01-CE: Flashing Instruction](#)
  - [Hardware Information](#)
  - [Serial Port Access](#)
  - [Setting up Bootloader:](#)
    - [Setting default U-boot environment](#)
  - [Flashing](#)
  - [Flashing RDKB image \(A Yocto Project based Distro\)](#)
  - [RDK Firmware\(Image\) upgrade:](#)
    - [Approach 1:](#)
    - [Approach 2\(Quick\):](#)
    - [Approach 3:](#)
  - [Fallback to OpenWrt OS\(Failsafe\):](#)