Firmware Upgradation for Rpi with Xconf Server by using RDK Services System Service -Plugin via UpdateFirmware curl command

- Introduction
- Yocto Build Steps
- Image Flash Procedure
- Firmware Upgrade Validation Procedure
 - TFTP Server Setup
 - XCONF Server Setup
 - XConf URL
 - Create Environments
 - Create Model
 - Create MAC List
 - Create Firmware config
 - Create Firmware Rule
 - Edit Download Location Round Robin Filter
 - Verify XConf server configuration
 - Activate the System Service Plugin in the Controller UI
 - Provide the UpdateFirmware Curl command in the Rpi board
 - Provide the opdater initiate Curr command in the R
 RPI-Board
- Conclusion

Introduction

The Firmware upgrade will upgrade higher or lower version of the current image in RPI target with the help of Xconf server and Local TFTP server by using Rdk Services

System Services-Plugin via updateFirmware curl command .

Yocto Build Steps

Refer below link to build rdkv image

Yocto Build Instructions - RPi - RDK Video - 2020 - M12#196872666

Image Flash Procedure

Image Flash step

```
$ sudo dd if="Image Name" of="Device Name" bs=4M
Example:
sudo dd if=rdk-generic-hybrid-wpe-image_default_20201221142654.rootfs.rpi-sdimg of=/dev/sdb bs=4M
```

Firmware Upgrade Validation Procedure

TFTP Server Setup

STEP 1:

Install xinetd and tftpd-hpa application in your local PC to setup tftp server by using below command TFTP Server Installation Step

STEP 2:

Create checksum file for your upgrading image. md5sum checksum creation

```
md5sum "<imagefile_name>.rootfs.rpi-sdimg" > imagefile_name.txt
```

for Ex:

```
upgrading image file is rdk-generic-hybrid-wpe-image_default_20201221142654.rootfs.rpi-sdimg
md5sum "rdk-generic-hybrid-wpe-image_default_20201221142654.rootfs.rpi-sdimg" > rdk-generic-hybrid-wpe-
image_default_20201221142654.txt
```

STEP 3:

Create new folder for example "tfphome" in your PC home directry to maintain checksum file and upgrading image file.

Keep upgrading image file and checksum file in your created folder.

For Ex:

Keep rdk-generic-camera-image_default_20200329074421.rootfs.rpi-sdimg and rdk-generic-camera-image_default_20200329074421.txt files in your tftphome folder.

STEP 4:

Check tftp file is there or not in /etc/xinetd.d/ directory. if it is not there then create tftp file under this /etc/xinetd.d/ directory and add below content.

vi /etc/xinetd.d/tftp TFTP File Content

<pre>service tftp {</pre>	
protocol	= udp
port	= 69
socket_type	= dgram
wait	= yes
user	= nobody
server	= /usr/sbin/in.tftpd
server_args	= -c -v -s /home/xyz/tftphome (Give upgrading file and checksum file maintained directory)
disable	= no
}	

STEP 5:

Verify /etc/default/tftpd-hpa file content

vi /etc/default/tftpd-hpa tftp-hpa File Content

```
# /etc/default/tftpd-hpa
```

```
TFTP_USERNAME="tftp"
TFTP_DIRECTORY="/home/xyz/tftphome"( Give upgrading file and checksum file maintained directory )
TFTP_ADDRESS="0.0.0.0:69"
TFTP_OPTIONS="--secure"
```

STEP 6:

Start tftp server and xinetd server

sudo service tftpd-hpa restart
sudo /etc/init.d/xinetd restart

XCONF Server Setup

XConf URL

Enter XConf server wiki page with below URL to create Environment, Model, Mac list, Firmware config, Firmware rule and Download Location Round Robin Filter.

XConf URL

http://35	155 171	121:9093/=	dmin/ux
11000-1100		121.2022/0	country are

Create Environments

STEP 1:

Select Environments option within common list to enter Environments page.

After entered Environments page press create button to add your device environment detail.

\leftarrow	C 🛈	 35.155.171. 	121:9093/admin/ux/#/environment/all?pageNumber=1&pageSize=50	⊘ ☆
	Conf	Common - Firmw	are - DCM - Telemetry - Settings - RFC - Tools -	Application First C+ 05/29/2020 UTC 01:51:15
	Environ	Environments Models	Search by Id	+ Create + Zexport All
	ld	MAC Lists IP Lists	Description	Actions
	AUSA-TEST		Altice-USA Validation Test	× 🛍 ±
	AX061AEI		RT1319	
	COGMATION_EN	٩V	Cogmation Test	× 💼 🛨

STEP 2:

Give ID and Description to setup Environment for your device and save that details in xconf server..

\leftarrow \rightarrow	C û	i 35.1	55.171.121:9093	/admin/ux/	/#/environment/	/edit/			··· 🗵 🛱	lii\
	Conf	Common -	Firmware 👻	DCM -	Telemetry -	Settings 👻	RFC -	Tools	Application	First C• 05/29/2020 UTC 01:59:22
	Environ	ment								
	Id RDK-C_	Test								
	Description	RDK-Camera								
	Save Cano	cel								

Create Model

STEP 1:

Select Models option within common list to enter Models page.

After entered Models page press create button to add your device model detail.

\leftrightarrow	C û	i 35.155.171.	121:9093/admin/ux/#/environment/all?pageNumber=1&pageSize=50	⊽ ☆
	Conf	Common - Firmw	rare • DCM • Telemetry • Settings • RFC • Tools •	Application First C 05/29/2020 UTC 02:00:19
	Enviror	Environments Models	Search by Id	+ Create - Zexport All
	ld	MAC Lists IP Lists	Description	Actions
	AUSA-TEST		Altice-USA Validation Test	
	AX061AEI		RT1319	
	COGMATION_EN	V	Cogmation Test	× 💼 ±

STEP 2:

Give ID and Description to setup Model for your device and save that details in xconf server..

\leftrightarrow	C û	i 35.1	55.171.121:9093	3/admin/ux,	/#/model/edit/				⊘ ☆	111
	Conf	Common 👻	Firmware 👻	DCM -	Telemetry -	Settings -	RFC -	Tools	- Applicatio	First 05/29/2020 UTC 02:01:38
	Model									
	Id RDK-C_T	est								
	Description	RPI0								
	Save Canc	el								

Create MAC List

STEP 1:

Select MAC Lists option within common list to enter MAC Lists page.

After entered MAC Lists page press create button to add your device MAC detail.

\leftarrow \rightarrow	C' û	i 35.155.171.	121:9093/admin/ux/#/model/all?pageNumber=1&pageSize=50	··· 🗟 🖓 🔤
	Conf	Common - Firmw	are - DCM - Telemetry - Settings - RFC - Tools -	Application First C 05/29/2020 UTC 02:02:41
	Models	Environments Models	Search by Id	+ Create - Zexport All
		MAC Lists		
	ld	IP Lists	Description	Actions
	AX061AEI		rt1319	× 💼 ±
	COGMATION_BB		Cogmation_BB_model	× 💼 ±
	EMULATOR		RDKB Emu	

Give Name and Data to set MAC detail for your device and save that details in xconf server..

\leftrightarrow \rightarrow (C' û	i 35.1	5 5.171.121 :9093	/admin/ux/	#/namespacedl	ist/edit//CREA	TE/MAC_LI	ST	***	פ ב	lii\
	Conf	Common 🗸	Firmware 👻	DCM -	Telemetry -	Settings 👻	RFC -	Tools 👻		Application	First C+ 05/29/2020 UTC 02:07:13
	Add MA	AC List							Choose File		Browse
	Name										
	RDK-C_Test										
	Data										
	Please enter iter	n									+
	B8:27:EB:2E:72	2:28 🗙									
	Save Cance	I									

Create Firmware config

Ensure application type is stb. If the application type is xhome then change application into stb.

STEP 1:

Select Firmware Configs option within common list to enter Firmware Configs page.

After entered Firmware Configs page press create button to add your device firmware configuration detail.

\leftrightarrow	C D	35.155.171.121:909	3/admin/ux	/#/namespaced	list/MAC_LIST	?pageNuml	ber=1&pageSize=50	⊘ ☆	lii\
		on - Firmware -	DCM -	Telemetry -	Settings -	RFC -	Tools 👻	Application F 05/24 UTC 02	irst ⊡ 9/2020 2:07:34
	Mac Lists	Firmware Co Firmware Ru Firmware Te	nfigs les mplates	•				+ Create - Export	All
	Name	Download Lo Percent Filte	cation Filter						
	AUSA-Test AX061AEI	Logs Report page							Ł
	Cogmation_MAC	Test page							Ł
	EMU-MAC		1					× 🛍 📀 🚽	Ł

STEP 2:

Give Description, File name (Upgrading image name), Version(Upgrading image name without .rootfs.rpi.sdimg) and select your model name and save the details in xconf server.

\leftrightarrow \rightarrow	C' 🕜	i 35.1	55.171.121:9093	/admin/ux/	/#/firmwarecon	fig/edit/				(פ ב	lii\
	Conf	Common 🗸	Firmware 👻	DCM -	Telemetry -	Settings -	RFC -	Tools	*		Application stb	First C+ 05/29/2020 UTC 02:15:59
	Firmwa	re con	fig									
	Description	RDK-C_Test										
	File name	rdk-generic-cam	era-image_defa	ult_2020032	29074421.rootfs.	rpi-sdimg						
	Version rdł	k-generic-camer	a-image_default	_202003290)74421							
	Models:											
	AX061AEI CC	DGMATION_BB	EMULATOR	EMULATO	R1 MOCKRT1:	319_TEST TES	T RDK-C	_TEST				
	RDKB-TECHSU	JMMIT RDKB	RPI RPI RP	IO RPI_BB	TESTCPE							
	Save	cel										

Create Firmware Rule

STEP 1:

Select Firmware Rule option within common list to enter Firmware Rule page.

After entered Firmware Rule page press create button to add your device firmware Rule detail.

\leftarrow	C û	۹ 35.1	55.171.121 :9093/admin/ux/#	#/firmwareconfig/all		\
	Conf	Common 🗸	Firmware - DCM -	Telemetry - Settings - RFC - Tools -	Applic: stb	ation First C+ 05/29/2020 UTC 02:16:54
1	_ :		Firmware Configs			
	Firmwar	e con	Firmware Rules	rch by Model	Create	Export All
			Firmware Templates			
	De	scription	Download Location Filter		Supported Models A	ctions
	Co	gmation_confi	Percent Filter	-broadband-image_default_20200406103506.txt	COGMATION_BB	× 💼 🛨
	© CF	Efirmaware	Logs Report page		TESTCPE	> 1
	em	nulator_firmwar	Test page	IYB_default_20200416061502	EMULATOR1	/ 🛍 🛨
	• Fir	mware_Camera	ı rdk-generic	-camera-image_default_20200527100029	RPIO	/ 1 ±

STEP 2:

After entered firmware Rule page you can see list of template.

Choose MAC_RULE in this list of Template to add your device MAC list in Firmware Configuration.

\leftrightarrow >	C û	۹ 35.1	55.171.121:9093	8/admin/ux/	/#/firmwareconl	ig/all			III
	Conf	Common 👻	Firmware 👻	DCM -	Telemetry -	Settings -	RFC -	Tools -	Application First C stb UTC 02:22:05
	Add Fir	mware	Rule						
	Please S	elect a	Templa	te					
	ENV_MODEL_R	ULE							
	IP_RULE								
	IV_RULE								
	MAC_RULE								
	MIN_CHECK_R	ULE							

STEP 3:

After entered Firmware Rule page. If any estbmac if there under build condition then remove that estmac before add your device specific Firmware rules.

st 🕒 2020 22:05

STEP 4:

Add your device specific eStbMac under build condition option.

Select your firmware config under Action option and save your Firmware rule in XConf server.

→ C û Ø 2 35.155.171.121:9093/admin/ux/#/firmwarerule/add/RULE/	… ⊠ ☆	lii\ 🗉 🏵
Conf Common - Firmware - DCM - Telemetry - Settings - RFC - Tools -	Applica	tion First C+ 05/29/2020 UTC 02:20:26
Add Firmware Rule		
PROPERTIES		
Name RDK-C_Test Type MAC_RULE		
BUILD CONDITIONS		
eSibMac IN_LIST RDK-C_Test		
Please provide value for each condition in the rule: click condition, enter fixedArg value, then click Plus button to save that condition. Note: Key value in condition <u>can't</u> be modified. It's not allowed to add new conditions.		
ACTION		
Action Type RULE		
Action Type RULE NoOp false		

Edit Download Location Round Robin Filter

STEP 1:

Select Download Location Filter option within common list to enter Download Location Filter page.

After entered Download Location Filter page press create button to add your Download Location detail.

\leftarrow \rightarrow	C 🗅	्र 35.1	55.171.121:9093/admin/ux	/#/firmwareconfig/all			\		
		imon 👻	Firmware - DCM -	Telemetry - Settings -	RFC - Tools -	Applic stb	ation First (+ 05/29/2020 UTC 02:24:45		
Firmware Rule		Firmware Configs Firmware Rules Firmware Templates	rch by Name		+ Create - Export All -				
	Rule Actions		Download Location Filter Percent Filter	Blocking Filters	• Tem	plate:	•		
			Logs Benort nage	Rule	Targeted Models	Configuration			
Cogmation_BE		n_BB	Test page	ogmation_MAC	COGMATION_BB	Cogmation_config	✓ mml mml mml mml mml mml mml mml mml mm		
	Deepthi_te	est	eStbMac IS B8:2	7:EB:15:07:5E	RPI	RDKV_test	ا ش ل		

STEP 2:

After entered Download Location Round Robin filter press edit button to edit your image downloading details.

Enable Never use HTTP and select your Rongue model.

Give TFTP server running IP address to download image.

→ C ŵ 0 35.155.171.121:9093/admin/ux/#/roundrobinfilter/edit	🗵	1		lii\ 🖸	۲	≡
Common - Firmware - DCM - Telemetry - Settings - RFC - Tools -		A	stb	05/29 UTC 02:	st 🕒 /2020 27:26	
Download Location Round Robin Filter						
НТТР						
Location (FQDN): www.myfirmware.com						
Location (full HTTP locaiton) http://myfirmware.com						
Never use HTTP: If this box is checked TFTP location will always be used no matter what the STB sends) Rogue models:						
AX061AEI COGMATION_BB EMULATOR EMULATOR MOCKRT1319_TEST TEST RDK-C_TEST RDKB-TECHSUN	IMIT					
RDKB_RPI RPI RPIO RPI_BB TESTCPE						
Firmware versions						
Type here						
TFTP						
IPv4 locations:						
192.168.0.107 100 %						
IPv6 locations:						
+						
Save Cancel						

Verify XConf server configuration

Verify that XConf Server configuration displays the Json response from the mentioned URL:

http://<Xconf Server IP:port no.>/xconf/swu/stb?eStbMac=<MAC address of Rpi board>

For Ex: http://35.155.171.121:9092/xconf/swu/stb?eStbMac=B8:27:EB:2E:72:2B

(←) → C'	(i) 35.155.171.121:9092/xconf/swu/stb?eStbMac=B8:27:EB:2E:72:2B					
JSON Raw Data Headers						
Save Copy Collapse All Expand All						
firmwareDownloadProtocol:	"tftp"					
<pre>▼ firmwareFilename:</pre>	"rdk-generic-camera-image_default_20200329074421.rootfs.rpi-sdimg"					
firmwareLocation:	"192.168.1.102"					
firmwareVersion:	"rdk-generic-camera-image_default_20200329074421"					
rebootImmediately:	false					

Activate the System Serivce Plugin in the Controller UI

http://<ip_address_pi_board>:9998

For Example:http://192.168.1.2:9998

Activitie	es 🛛 🐞 Firefox Web	Browser 🔻				Sat 12:	15						rj		? () (Î	•
				N	Aetrologi	al Thunder l	JI - Mozil	lla Firefox									
:	न System - RD 🗙	35.155.171.1 21	🗙 🛛 🍁 Redirecting. 🗙	न Firmware	e U (🗙 🕴	Getting Sta	r 🗙 🔤	Raspberry	P 🗙 🔤	Firmware	UFX	न Firmw	vare U⊨ X	Metro	logical	Th ×	+
	← → ♂ ଢ		🗊 🔏 192.168.1.2 :9998	/Service/Conl	troller/UI?i	p=0.0.0.0&po	rt=9998					⊠ ☆		li	\ 🗉	۲	≡
	Controller		org.rdk.DisplaySettings														
•	Device Info		org.rdk.FrameRate														
?	Location		org.rdk.HdcpProfile														
• 📝	Monitor		org.rdk.LoggingPrefere														
<u>}_</u>	Tracing		org.rdk.Network							.System" (lata: {sta	ate: activat	ed, reaso	n: Reques	sted}		
<u></u>			org.rdk.PersistentStore														
• 🏵			org.rdk.RDKShell								1.0.#724 OEuCfr	111826fff0 ⁻ 9Z8p	7d449619	a4263e1c	lf21fbd2	811f4	
• 🔫			org.rdk.ScreenCapture								4000 14.0 %						
•			org.rdk.System								194.4 M	B / 610.0 M	ИВ				
(:::			org.rdk.TextToSpeech						Last key	v send	-		,				

Provide the UpdateFirmware Curl command in the Rpi board

```
root@raspberrypi-rdk-hybrid:~# curl --data-binary '{"jsonrpc":"2.0","id":"3","method":"org.rdk.System.1.
updateFirmware","params":{}}' -H 'cont
ent-type:text/plain;' http://localhost:9998/jsonrpc
```

RPI-Board

- 1. Flash the RDKV image supported for Firmware upgrade feature in the Rpi and verify the 2 partitions(ex. mmcblk0p1, mmcblk0p2) present under dev folder (use command Is /dev)
- 2. Verify System Service plugin is activated in controller UI as: http://<ip_address_pi_board>:9998
- 3. Provide the updateFirmware curl command on the pi board ex: root@raspberrypi-rdk-hybrid:~# curl --data-binary '{"jsonrpc":"2.0","id":" 3","method":"org.rdk.System.1.updateFirmware","params":{}}' -H 'content-type:text/plain;' http://localhost:9998/jsonrpc
- 4. Device auto-reboots and verify there are 2 more additional partitions are created (ex. mmcblk0p3, mmcblk0p4).
- 5. After the board gets auto-reboots for creation of 2 more additional partitions (ex. mmcblk0p3, mmcblk0p4). Again activate the System Service plugin in controller UI as: http://<ip_address_pi_board>:9998
- 6. Provide the updateFirmware curl command on the pi board ex: root@raspberrypi-rdk-hybrid:~# curl --data-binary '{"jsonrpc":"2.0","id":" 3","method":"org.rdk.System.1.updateFirmware","params":{}}' -H 'content-type:text/plain;' http://localhost:9998/jsonrpc
- 7. Open /etc/include.properties file and verify the CLOUDURL parameter where XConf Server URL is configured
- 8. Verify the image version (cat /version.txt) displays the flashed image version
- 9. Open /opt/logs/swupdate.log to verify the communication from RPI board with XConf Server and the download status
- 10. Verify the tftp download is happening by noticing the change of file size using below command: Is /extblock/tftpimage/imagedwnldls -sh (use this command frequently to verify the file size change)
- 11. Once image download completed, the Rpi board will auto reboot and come up with downloaded image
- 12. Verify the version of booted image which shows the downloaded image version

Conclusion

Please find the summary on firmware upgrade explained above

- Build the image RDK-V Image.
 Ensure 8GB sd-card is available for flashing
 Flash the build image to sd-card
 Setup xconf server ready with rules and download location for RPI device
 Place the upgrading image and checksum file in tftp server

- Boot the flashed image
 Activation of System Service plugin in controller UI before executing Curl command
 Curl command need to be provide twice initiailly after the RPI board bootup ,curl command for the creation of 2 more additional partitions (ex. mmcblk0p3, mmcblk0p4) in /dev folder.and again after the auto-reboot of the RPI board curl command for image download