

RDKC : CVR Feature with Pipewire

- [Introduction](#)
- [Build and Flash Procedure](#)
- [AWS Account and IOT credential creation steps](#)
- [CVR Validation Procedure](#)

Introduction

This page dedicated to bringing up and validation of Continuous video recording functionality in RPI-3 B+.

CVR using pipewire callback to receive frames from v4l2 and also it using AWS Kinesis Video Stream(KVS) to perform 24/7 video recording with AWS IOT credential.

Build and Flash Procedure

Refer below link to build camera image

Morty:

[RDK-C Build Instruction for RPI-0](#)

[RDK-C Build Instruction for RPI-3](#)

Dunfell:

[RDK-C rdk-next Yocto 3.1 dunfell build for Raspberrypi](#)

AWS Account and IOT credential creation steps

STEP 1:

AWS account is needed for to validate CVR use case. so, Refer below link to create AWS account.

[Procedure To Create AWS Account](#)

After the AWS account creation, Refer same link to create Access key ID ,Secret Access Key and Region Name of your AWS account.

STEP 2:

After the AWS account creation, Need to create IOT credential with AWS CLI interface to validate CVR use case.

Use the below link to install AWS CLI interface package for to create AWS IOT credential.

Please install this AWS CLI package in your local linux pc. we can interact AWS account through our local linux pc with this AWS CLI interface.

<https://docs.aws.amazon.com/cli/latest/userguide/install-cliv2-linux.html#cliv2-linux-install>

Follow the below command to create config and credentials file in your local PC to interact AWS account

AWS Configure

```
$ aws configure

AWS Access Key ID [None]: XXXXXXXXXX ( Give your AWS account Access Key ID )
AWS Secret Access Key [None]: YYYYYYYYYYYY ( Give your AWS Secret Key )
Default region name [None]: ZZZZZZZZZZ ( Give your Region Name )
Default output format [None]: json
```

Onw you done this **aws configure** in your local PC automatically below files will be create with below content. so, please cross check whether that is created or not

AWS Configure

```
vi ~/.aws/config

[default]
region = ZZZZZZZZZZ
output = json
```

AWS Configure

```
vi ~/.aws/credentials

[default]
aws_access_key_id = XXXXXXXXX
aws_secret_access_key = YYYYYYYYYYYY
```

use the below link to create AWS IOT credential

<https://docs.aws.amazon.com/kinesisvideostreams/latest/dg/how-iot.html>

After created the IOT credential you will get below list of details

Stream Name, Default Region, IOT Credential Endpoint, Certificate key, Private Key, Role Alias and cacertificate key

Move the certificate.pem,private.pem.key and cacert.pem keys into your RPI /etc/ssl/certs/ directory

CVR Validation Procedure

STEP 1:

Add require SSID and PSK in /etc/wpa_supplicant.conf file in below format

```
network={
ssid="username"
psk="password"
}
```

Console output

```
ctrl_interface=/var/run/wpa_supplicant
ctrl_interface_group=0
update_config=1

network={
ssid="RDK"
psk="Comcast1"
}
```

STEP 2:

Reboot the Target

After Reboot don't do step 1 and 2.

Note : Step 1 & 2 is only applicable for fresh target boot-up with new image.

STEP 3:

WiFi connection is must needed for CVR-AWS validation.

Check WiFi connection by using below command.

ifconfig

Console output

```
root@raspberrypi3-rdk-camera:~# ifconfig
lo          Link encap:Local Loopback
            inet addr:127.0.0.1  Mask:255.0.0.0
            inet6 addr: ::1/128 Scope:Host
            UP LOOPBACK RUNNING  MTU:65536  Metric:1
            RX packets:87 errors:0 dropped:0 overruns:0 frame:0
            TX packets:87 errors:0 dropped:0 overruns:0 carrier:0
            collisions:0 txqueuelen:1000
            RX bytes:4552 (4.4 KiB)  TX bytes:4552 (4.4 KiB)

wlan0       Link encap:Ethernet  HWaddr B8:27:EB:2E:72:2B
            inet addr:192.168.43.246  Bcast:192.168.43.255  Mask:255.255.255.0
            UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
            RX packets:23 errors:0 dropped:0 overruns:0 frame:0
            TX packets:44 errors:0 dropped:0 overruns:0 carrier:0
            collisions:0 txqueuelen:1000
            RX bytes:2893 (2.8 KiB)  TX bytes:5887 (5.7 KiB)
```

STEP 4:

Give the below environment variable in your RPI target. Based on this details the frame will upload into AWS KVS.

export STREAM_NAME="XXXXXXX"

export AWS_DEFAULT_REGION="YYYYYYYYY"

export IOT_GET_CREDENTIAL_ENDPOINT="ZZZZZZZ"

export CERT_PATH="/etc/ssl/certs/certificate.pem"

export PRIVATE_KEY_PATH="/etc/ssl/certs/private.pem.key"

export ROLE_ALIAS="WWWWWWW"

export CA_CERT_PATH="/etc/ssl/certs/cacert.pem"

Console output

```
root@raspberrypi3-rdk-camera:~# export STREAM_NAME="XXXXXXX"
root@raspberrypi3-rdk-camera:~# export AWS_DEFAULT_REGION="YYYYYYYYY"
root@raspberrypi3-rdk-camera:~# export IOT_GET_CREDENTIAL_ENDPOINT="ZZZZZZZ"
root@raspberrypi3-rdk-camera:~# export CERT_PATH="/etc/ssl/certs/certificate.pem"
root@raspberrypi3-rdk-camera:~# export PRIVATE_KEY_PATH="/etc/ssl/certs/private.pem.key"
root@raspberrypi3-rdk-camera:~# export ROLE_ALIAS="WWWWWWW"
root@raspberrypi3-rdk-camera:~# export CA_CERT_PATH="/etc/ssl/certs/cacert.pem"
```

STEP 5:

Check exported AWS IOT credential by using below command.

printenv

Console output

```
root@raspberrypi3-rdk-camera:~# printenv
CERT_PATH=/etc/ssl/certs/certificate.pem
CA_CERT_PATH=/etc/ssl/certs/cacert.pem
ROLE_ALIAS=WWWWWWW
TERM=xterm
SHELL=/bin/sh
SSH_CLIENT=::ffff:192.168.1.4 50911 22
SSH_TTY=/dev/pts/0
USER=root
PRIVATE_KEY_PATH=/etc/ssl/certs/private.pem.key
SYSTEMD_PAGER=/bin/cat
STREAM_NAME=XXXXXXX
PATH=/usr/local/bin:/usr/bin:/bin:/usr/local/sbin:/usr/sbin:/sbin
AWS_DEFAULT_REGION=YYYYYYYY
PWD=/home/root
EDITOR=vi
PS1=\u@\h:\w\$
SHLVL=1
HOME=/home/root
LOGNAME=root
SSH_CONNECTION=::ffff:192.168.1.4 50911 ::ffff:192.168.1.2 22
RMF_USE_SOUPHTTPSRC=TRUE
DISPLAY=localhost:10.0
IOT_GET_CREDENTIAL_ENDPOINT=ZZZZZZ
_=/bin/printenv
```

STEP 6:

Before triggering CVR binary we should stop rms binary and mediastreamer binary with below command.

```
systemctl stop rms-launcher
```

```
systemctl stop mst-launcher
```

STEP 7:

Before start the CVR binary please check the current date and time in RPI with "**date**" command, If you get wrong date and time please manually set current date and time with the below command.

```
date -s "Mon Nov 30 03:42:44 UTC 2020"
```

Console output

```
root@raspberrypi3-rdk-camera:~# date -s "Mon Nov 30 03:42:44 UTC 2020"
Mon Nov 30 03:42:44 UTC 2020
root@raspberrypi3-rdk-camera:~# date
Mon Nov 30 03:43:55 UTC 2020
```

STEP 8:

Run the pipewire binary with below command

```
pipewire &
```

pipewire:Console output

```
root@raspberrypi3-rdk-camera:~# pipewire &
```

STEP 9:

Run the pipewire media session binary with below command

pipewire-media-session &

pipewire-media-session:Console output

```
root@raspberrypi3-rdk-camera:~# pipewire-media-session &
```

STEP 10

Run the cvr binary

cvr_daemon_kvs2 &

pipewiresrc:Console output

```
root@raspberrypi3-rdk-camera:~# cvr_daemon_kvs2 &
```

STEP 11:

Enter into AWS account and select the corresponding video stream service which was we created for streaming.

Press "Media Playback" option on the video stream player.


Streaming video content should decode properly on AWS.

Kinesis Video Streams ✕

DashboardVideo streams (selected)Signaling channelsDocumentation (external link)What's new (external link)

▼ Media playback

2020/04/3016:03:33ISTServer timestamp



Live -15.5 s

⏮⏪⏸⏩⏭

Download clip