# Firmware Upgrade validation in RPI-3 target

- Introduction
- Yocto Build Steps
- Image Flash Procedure
- Firmware Upgrade Validation Procedure
  - TFTP Server Setup
    - XCONF Server Setup
      - XConf URL
      - Create Environments
      - Create Model
      - Create MAC List
      - Create Firmware config
      - Create Firmware Rule
      - Edit Download Location Round Robin Filter
      - Verify XConf server configuration
    - RPI-Board
- Conclusion
- Limitations

## Introduction

The Firmware upgrade will upgrade higher or lower version of the current image in RPI target with the help of Xconf server and Local TFTP server.

This page dedicated to bringing up and validation of Firmware upgrade in RPI 3B+ target.

## **Yocto Build Steps**

Refer below link to build camera image

**RDK-C Build Instruction for RPI-3** 

## **Image Flash Procedure**

#### Image Flash step

```
$ sudo dd if="Image Name" of="Device Name" bs=4M
```

```
Example:
```

sudo dd if=rdk-generic-camera-image\_default\_20200130060729.rootfs.rpi-sdimg of=/dev/sdb bs=4M

## **Firmware Upgrade Validation Procedure**

## **TFTP Server Setup**

#### STEP 1:

Install xinetd and tftpd-hpa application in your local PC to setup tftp server by using below command

#### **TFTP Server Installation Step**

```
sudo apt-get install xinetd
sudo apt-get install tftpd-hpa
```

#### STEP 2:

Create checksum file for your upgrading image.

#### md5sum checksum creation

```
md5sum "<imagefile_name>.rootfs.rpi-sdimg" > imagefile_name.txt
```

for Ex:

```
upgrading image file is rdk-generic-camera-image_default_20200329074421.rootfs.rpi-sdimg
md5sum "rdk-generic-camera-image_default_20200329074421.rootfs.rpi-sdimg" > rdk-generic-camera-
image_default_20200329074421.txt
```

#### STEP 3:

Create new folder for example "tfphome" in your PC home direcotry to maintain checksum file and upgrading image file.

Keep upgrading image file and checksum file in your created folder.

For Ex:

Keep rdk-generic-camera-image\_default\_20200329074421.rootfs.rpi-sdimg and rdk-generic-camera-image\_default\_20200329074421.txt files in your tftphome folder.

#### STEP 4:

Check tftp file is there or not in /etc/xinetd.d/ directory. if it is not there then create tftp file under this /etc/xinetd.d/ directory and add below content.

#### vi /etc/xinetd.d/tftp

TFTP File Content	
<pre>service tftp {   protocol   port   socket_type   wait   user   server   server_args   disable  }</pre>	<pre>= udp = 69 = dgram = yes = nobody = /usr/sbin/in.tftpd = -c -v -s /home/xyz/tftphome ( Give upgrading file and checksum file maintained directory ) = no</pre>

#### STEP 5:

Verify /etc/default/tftpd-hpa file content

vi /etc/default/tftpd-hpa

#### tftp-hpa File Content

```
# /etc/default/tftpd-hpa
```

```
TFTP_USERNAME="tftp"
TFTP_DIRECTORY="/home/xyz/tftphome" ( Give upgrading file and checksum file maintained directory )
TFTP_ADDRESS="0.0.0.0:69"
TFTP_OPTIONS="--secure"
```

#### STEP 6:

Start tftp server and xinetd server

```
sudo service tftpd-hpa restart
sudo /etc/init.d/xinetd restart
```

## **XCONF Server Setup**

### XConf URL

Enter XConf server wiki page with below URL to create Environment, Model, Mac list, Firmware config, Firmware rule and Download Location Round Robin Filter.

#### XConf URL

http://35.155.171.121:9093/admin/ux

#### **Create Environments**

#### STEP 1:

Select Environments option within common list to enter Environments page.

After entered Environments page press create button to add your device environment detail.

$\leftrightarrow$ $\rightarrow$	C' û	i 35.155.171.	121:9093/admin/ux/#/environment/all?pageNumber=1&pageSize=50	⊘ ☆
	Conf	Common - Firmw	are - DCM - Telemetry - Settings - RFC - Tools -	Application First C 05/29/2020 UTC 01:51:15
	Enviror	Environments Models	Search by Id	+ Create - Export All
	ld	MAC Lists IP Lists	Description	Actions
	AUSA-TEST		Altice-USA Validation Test	
	AX061AEI		RT1319	
	COGMATION_EN	V	Cogmation Test	

#### STEP 2:

Give ID and Description to setup Environment for your device and save that details in xconf server..

$\leftarrow$	C 🛈	i 35.15	5.171.121:9093	/admin/ux/	#/environment/	'edit/			🗵 🕁	111\
	Conf	Common 🗸	Firmware 👻	DCM -	Telemetry -	Settings 👻	RFC -	Tools -	Application	First C+ 05/29/2020 UTC 01:59:22
	Environ	ment								
	Id RDK-C_T	est								
	Description	RDK-Camera								
	Save	el								

#### **Create Model**

STEP 1:

Select Models option within common list to enter Models page.

### After entered Models page press create button to add your device model detail.

$\leftarrow$ $\rightarrow$	C û	i 35.155.171.	121:9093/admin/ux/#/environment/all?pageNumber=1&pageSize=50	⊽ ☆
	Conf	Common - Firmw	rare • DCM • Telemetry • Settings • RFC • Tools •	Application First C+ 05/29/2020 UTC 02:00:19
	Environ	Environments Models	Search by Id	+ Create - Zexport All
	Id	MAC Lists	Recription	Actions
	IN .	IP Lists	Description	
	AUSA-TEST		Altice-USA Validation Test	× 🛍 ±
	AX061AEI		RT1319	× 🛍 🛨
	COGMATION_EN	V	Cogmation Test	<ul> <li>m</li> </ul>

### STEP 2:

Give ID and Description to setup Model for your device and save that details in xconf server..

$\leftrightarrow$ $\rightarrow$	C' û	i 35.1	55.171.121:9093	/admin/ux/	/#/model/edit/				🗵 📩	lii\
	Conf	Common -	Firmware 👻	DCM -	Telemetry -	Settings -	RFC -	Tools	Application	First C+ 05/29/2020 UTC 02:01:38
	Model									
	Id RDK-C_T	est								
	Description	RPI0								
	Save	əl								

## **Create MAC List**

### STEP 1:

Select MAC Lists option within common list to enter MAC Lists page.

After entered MAC Lists page press create button to add your device MAC detail.

$\leftarrow$	C û	i) 35.155.171.	121:9093/admin/ux/#/model/all?pageNumber=1&pageSize=50	⊘ ☆
	Conf	Common - Firmw	rare - DCM - Telemetry - Settings - RFC - Tools -	Application First C 05/29/2020 UTC 02:02:41
	Models	Environments Models	Search by Id	+ Create - Export All
		MAC Lists		
	ld	IP Lists	Description	Actions
	AX061AEI		rt1319	<ul> <li></li></ul>
	COGMATION_BB		Cogmation_BB_model	<ul> <li></li></ul>
	EMULATOR		RDKB Emu	<ul> <li></li></ul>

#### STEP 2:

Give Name and Data to set MAC detail for your device and save that details in xconf server..

$\leftrightarrow$ $\rightarrow$	C' û	i 35.1	<b>55.171.121</b> :9093	/admin/ux/	/#/namespacedl	ist/edit//CREA	TE/MAC_LI	IST		⊌ ☆	lii\
	Conf	Common 👻	Firmware 👻	DCM -	Telemetry -	Settings <del>-</del>	RFC -	Tools 👻		Application	First C+ 05/29/2020 UTC 02:07:13
	Add MA	AC List							Choose File		Browse
	Name										
	RDK-C_Test										
	Data										
	Please enter iten	n									+
	B8:27:EB:2E:72 Save Cancel	:2B ¥									

### **Create Firmware config**

Ensure application type is stb. If the application type is xhome then change application into stb.

### STEP 1:

Select Firmware Configs option within common list to enter Firmware Configs page.

After entered Firmware Configs page press create button to add your device firmware configuration detail.

$\leftarrow$ $\rightarrow$	C 🛈 🕕	35.155.171.121:9093/admin/ux	/#/namespacedlist/MAC_LIST?pa	geNumber=1&pageSize=50	⊘ ☆
		n → Firmware → DCM →	Telemetry - Settings - F	RFC - Tools -	Application First C 05/29/2020 UTC 02:07:34
	Mac Lists	Firmware Configs Firmware Rules Firmware Templates			+ Create - Export All
	Name	Download Location Filter Percent Filter			
	AUSA-Test	Logs			
	AX061AEI	Report page	_		<ul> <li>Image: Image: Ima</li></ul>
	Cogmation_MAC	Test page			× 🛍 😣 Ł
	EMU-MAC	1			L © ±

#### STEP 2:

Give Description, File name (Upgrading image name), Version(Upgrading image name without .rootfs.rpi.sdimg) and select your model name and save the details in xconf server.

$\leftrightarrow$ $\rightarrow$	C' 🕜	i 35.1	55.171.121:9093	/admin/ux/	/#/firmwarecon	fig/edit/				(	פ ב	lii\
	Conf	Common 🗸	Firmware 👻	DCM -	Telemetry -	Settings -	RFC -	Tools	*		Application stb	First C+ 05/29/2020 UTC 02:15:59
	Firmwa	re con	fig									
	Description	RDK-C_Test										
	File name	rdk-generic-cam	era-image_defa	ult_2020032	29074421.rootfs.	rpi-sdimg						
	Version rdł	k-generic-camer	a-image_default	_202003290	)74421							
	Models:											
	AX061AEI CC	DGMATION_BB	EMULATOR	EMULATO	R1 MOCKRT1:	319_TEST TES	T RDK-C	_TEST				
	RDKB-TECHSU	JMMIT RDKB	RPI RPI RP	IO RPI_BB	TESTCPE							
	Save	cel										

## **Create Firmware Rule**

### STEP 1:

Select Firmware Rule option within common list to enter Firmware Rule page.

After entered Firmware Rule page press create button to add your device firmware Rule detail.

$\leftarrow$	C û	٩ 35.1	<b>55.171.121</b> :9093/admin/ux/#	#/firmwareconfig/all		\
	Conf	Common 🗸	Firmware - DCM -	Telemetry - Settings - RFC - Tools -	Applic: stb	ation First C+ 05/29/2020 UTC 02:16:54
1	<b>_</b> :		Firmware Configs			
	Firmware con		Firmware Rules	rch by Model	Create	Export All
			Firmware Templates			
	De	scription	Download Location Filter		Supported Models A	ctions
	Co	gmation_confi	Percent Filter	-broadband-image_default_20200406103506.txt	COGMATION_BB	× 💼 🛨
	© CPEfirmaware		Logs Report page		TESTCPE	> 1
	em	nulator_firmwar	Test page	IYB_default_20200416061502	EMULATOR1	/ 🛍 🛨
	• Fir	mware_Camera	ı rdk-generic	-camera-image_default_20200527100029	RPIO	/ <b>1 ±</b>

### STEP 2:

After entered firmware Rule page you can see list of template.

Choose MAC\_RULE in this list of Template to add your device MAC list in Firmware Configuration.

$\leftrightarrow$ ) (	C û	٩ 35.1	5 <b>5.171.121</b> :9093	/admin/ux/	/#/firmwareconf	ig/all			111		
	Conf	Common -	Firmware 👻	DCM -	Telemetry -	Settings <del>-</del>	RFC -	Tools 🗸	Application First 55/29/2020 55/29/202 55/202 55/20 55/29/202 55/202 55/20 55/		
	Add Firi	mware	Rule								
	Please Select a Template										
	ENV_MODEL_R	ULE									
	IP_RULE										
	IV_RULE										
	MAC_RULE										
	MIN_CHECK_RU	JLE									

#### STEP 3:

After entered Firmware Rule page. If any estbmac if there under build condition then remove that estmac before add your device specific Firmware rules.

$\leftrightarrow$	C' û		् ३५.१५५.१७	<b>1.121</b> :9093/adn	nin/ux/#/firmwarecor	nfig/all			١١١
	Con	f Comm	on 👻 Firm	iware - DCM	M - Telemetry -	Settings -	RFC - Tools -	Application stb JUTC	First C+ 29/2020 02:22:05
	Add F	-irmw	are R	ule					
	PROPERT	IES							
	Name	RDK-C_Test				Ту	pe MAC_RULE		
	BUILD CO	NDITIONS							
	eStbMac	IN_LIST	2		IST V				
	Unit		-						
	Please pr click cond Note: Key	ovide value for e lition, enter fixed value in conditi	each condition in Arg value, then o on <u>can't</u> be modi	the rule: click Plus button to fied. It's not allowe	save that condition. d to add new conditions.				

#### STEP 4:

Add your device specific eStbMac under build condition option.

Select your firmware config under Action option and save your Firmware rule in XConf server.

→ C û Ø 2 35.155.171.121:9093/admin/ux/#/firmwarerule/add/RULE/	… ⊠ ☆	lii\ 🗉 🏵
Conf Common - Firmware - DCM - Telemetry - Settings - RFC - Tools -	Applica	tion First C+ 05/29/2020 UTC 02:20:26
Add Firmware Rule		
PROPERTIES		
Name RDK-C_Test Type MAC_RULE		
BUILD CONDITIONS		
eSibMac IN_LIST RDK-C_Test		
Please provide value for each condition in the rule: click condition, enter fixedArg value, then click Plus button to save that condition. Note: Key value in condition <u>can't</u> be modified. It's not allowed to add new conditions.		
ACTION		
Action Type RULE		
Action Type RULE NoOp false		

## Edit Download Location Round Robin Filter

### STEP 1:

Select Download Location Filter option within common list to enter Download Location Filter page.

After entered Download Location Filter page press create button to add your Download Location detail.

$\leftarrow$ $\rightarrow$	C 🗅	्र 35.1	55.171.121:9093/admin/ux	/#/firmwareconfig/all			\
		imon 👻	Firmware - DCM -	Telemetry - Settings -	RFC - Tools -	Applic stb	ation First 05/29/2020 ↓ UTC 02:24:45
1	Firmware Ruli Firmware Configs Firmware Rules Firmware Templates		rch by Name		+ Create -	Z Export All	
	Rule Actions	Œ	Download Location Filter Percent Filter	Blocking Filters	• Tem	plate:	•
Name		ime	Logs Benort nage	Rule	Targeted Models	Configuration	
	• Cogmation	n_BB	Test page	ogmation_MAC	COGMATION_BB	Cogmation_config	✓ mm ⊥
	Deepthi_te	est	eStbMac IS B8:2	7:EB:15:07:5E	RPI	RDKV_test	ا ش ل

## STEP 2:

After entered Download Location Round Robin filter press edit button to edit your image downloading details.

Enable Never use HTTP and select your Rongue model.

Give TFTP server running IP address to download image.

) → C' û 0	35.155.171.121:9093/admin/ux/#/roundrobinfilter/edit	⊚ ☆	II\ 🖸 🌒
	Firmware - DCM - Telemetry - Settings - RFC - Tools -	Applic stb	eation First U 05/29/2020 UTC 02:27:26
Download Lo	ocation Round Robin Filter		
HTTP			
Location (FQDN): www	w.myfirmware.com		
Location (full HTTP locait	on) http://myfirmware.com		
Never use HTTP: 🛃 (if thi Rogue models:	s box is checked TFTP location will always be used no matter what the STB sends)		
AX061AEI COGMATION	BB EMULATOR EMULATORI MOCKRT1319_TEST TEST RDK-C_TEST RDKB-TECH	SUMMIT	
RDKB_RPI RPI RPI0	RPI_BB TESTCPE		
Firmware versions			
Type here			
		~	
TFTP			
IPv4 locations:			
192.168.0.107	100 %		
+			
IPv6 locations:			
+			
Save Cancel			

## Verify XConf server configuration

Verify that XConf Server configuration displays the Json response from the mentioned URL:

http://<Xconf Server IP:port no.>/xconf/swu/stb?eStbMac=<MAC address of Rpi board>

For Ex: http://35.155.171.121:9092/xconf/swu/stb?eStbMac=B8:27:EB:2E:72:2B

$\frown$						
$(\leftarrow)  ightarrow$ C' $\textcircled{a}$	③ 35.155.171.121:9092/xconf/swu/stb?eStbMac=B8:27:EB:2E:72:2B					
JSON Raw Data Headers						
Save Copy Collapse All Expand All						
firmwareDownloadProtocol: "t	itp"					
<pre>▼ firmwareFilename: "ro</pre>	"rdk-generic-camera-image_default_20200329074421.rootfs.rpi-sdimg"					
firmwareLocation: "19	192.168.1.102"					
firmwareVersion: "ro	dk-generic-camera-image_default_20200329074421"					
rebootImmediately: fal	se					

## **RPI-Board**

- 1. Flash the RDKC image supported for Firmware upgrade feature in the Rpi and verify the 2 partitions(ex. mmcblk0p1, mmcblk0p2) present under dev folder (use command ls /dev)
- Device auto-reboots and verify there are 2 more additional partitions are created (ex. mmcblk0p3, mmcblk0p4).
   Open /etc/include.properties file and verify the CLOUDURL parameter where XConf Server URL is configured
- 4. Verify the image version ( cat /version.txt) displays the flashed image version
- 5. Open /rdklogs/logs/swupdate.log to verify the communication from RPI board with XConf Server and the download status
- 6. Verify the tftp download is happening by noticing the change of file size using below command: Is /extblock/tftpimage/imagedwnldls -sh (use this command frequently to verify the file size change)
- 7. Once image download completed, the Rpi board will auto reboot and come up with downloaded image
- 8. Verify the version of booted image which shows the downloaded image version

## Conclusion

Please find the summary on firmware upgrade explained above

- · Build the image RDK-C Image.
- Ensure 8GB sd-card is available for flashing
- Flash the build image to sd-card
- · Setup xconf server ready with rules and download location for RPI device
- · Place the upgrading image and checksum file in tftp server
- · Boot the flashed image

#### Note :

1. RPI will go for reboot while booting for the first time, since two more partition needs to be created which requires reboot. Depends on the image present in xconf and RPI, further reboot will happen for upgrade. Please refer to design (RDK-C : Firmware Upgrade) for how firmware upgrade works with bank switching

2. SD card should be zero filled formatted before starting the firmware upgrade procedure. DriveWipe software is used for this. Please refer the you-tube video link for the SD card full format process.

#### https://youtu.be/CZhsVBEMYuk

## Limitations

RPI will support only tftp protocol . No http protocol support is provided yet.